ISA PROGRAM REPORT

Bhone Pyae Kyaw

6530327

Section - 541

Table of Contents

IS	A Architecture Design and Implementation Report	. 2
	1. ISA Overview	2
	1.1 Instruction Format	2
	1.2 Registers	2
	2. Supported Instructions	2
	3. Cycle Timing Justification	2
	4. Instruction Encoding and Decoding	3
	5. Execution Logic	3
	6. Performance Metrics	3
	7. Conclusion	3
	8. SIMULATION PROGRAM CODE	4

ISA Architecture Design and Implementation Report

1. ISA Overview

1.1 Instruction Format

Each instruction follows a fixed-length 32-bit structure, broken down into the following fields:

Field	Size (bits)		
Opcode	5 bits		
Target Reg	3 bits		
Source Reg	3 bits		
Immediate	21 bits		
Total	32 bits		

1.2 Registers

There are 8 General Purpose Registers (GPRs), identified as r0 through r7. They are represented by 3-bit binary codes as shown below:

Register Name	Code
r0	000
r1	001
r2	010
r3	011
r4	100
r5	101
r6	110
r7	111

2. Supported Instructions

The ISA supports five arithmetic and data manipulation instructions:

Instruction	Opcode	Description	Cycles
mov	00000	Move immediate or register	1
add	00001	Add immediate or register	1
sub	00010	Subtract immediate or register	1
mul	00011	Multiply immediate or register	4
div	00100	Divide immediate or register	6

3. Cycle Timing Justification

mov, add, sub: These are simple instructions that typically require only 1 cycle to execute.

mul: Requires 4 cycles due to increased computational complexity.

div: Requires 6 cycles, reflecting the more complex division compared to other instructions.

4. Instruction Encoding and Decoding

The **encode_instruction()** function converts human-readable instructions into their binary representation based on the instruction format. Immediate values are sign-extended to 21 bits, and registers are encoded as 3-bit fields.

Example:

Instruction: mov r1 25

Binary: 00000 001 000 00000000000011001

5. Execution Logic

The **execute_instructions()** function simulates a CPU fetching, decoding, and executing instructions. It supports:

- Handling immediate and register values.
- Performing arithmetic operations.
- Division-by-zero checking.
- Cycle count accumulation

6. Performance Metrics

- Total Cycle Count
- Total Instruction Count (excluding end)
- CPI (Cycles Per Instruction): Total Cycle Count / Total Instruction Count up to 2 decimal place.

7. Conclusion

The designed ISA and simulator demonstrates:

- Instruction encoding and decoding.
- Basic arithmetic and data manipulation.
- Cycle counting and performance measurement (CPI).

8. SIMULATION PROGRAM CODE

```
# ISA Architecture
     # 32 bits instruction
     # 8 general purpose registers r0 - r7
     # op-codes - mov, add, sub, mul, div
     # Encoded instruction structure
     # Opcode(5 bits) target_reg(3 bits) source_reg(3 bits) immi(21 bits) = 32 bits
10 \vee opcodes = {
11
         'mov' : '00000',
12
         'add' : '00001',
13
         'sub' : '00010',
14
         'mul' : '00011',
        'div' : '00100'
18 ∨ cycle_values = {
         '00000' : 1, #mov
         '00001' : 1, #add
21
         '00010' : 1, #sub
         '00011' : 4, #mul
         '00100' : 6 #div
23
25
26 \vee gprs = {
         'r0': '000',
         'r1': '001',
29
         'r2': '010',
         'r3': '011',
         'r4': '100',
         'r5': '101',
         'r6': '110',
         'r7': '111'
```

```
gprs_values = {
    '000' : 0,
    '001' : 0,
    '010' : 0,
    '011' : 0,
    '100' : 0,
    '101' : 0,
    '110' : 0,
    '111' : 0
def encode_instruction(instruction):
    #Opcode(5 bits) target_reg(3 bits) source_reg(3 bits) immi(21 bits) = 32 bits
    instruction_components = instruction.split()
    opcode = opcodes[instruction_components[0]]
    target_reg = gprs[instruction_components[1]]
    #check whether source register is a register or a number
    #for number case
    if instruction_components[2].lstrip('-').isnumeric():
        source_reg = '000'
        immi = int(instruction_components[2])
        #for handling negative value
        if immi < 0:
            immi = format((1 << 21) + immi, '021b')</pre>
        else:
            immi = format(immi & 0x1FFFFF, '021b')
```

```
70    else:
71         source_reg = gprs[instruction_components[2]]
72         immi = '0' * 21
73
74     # concatenate to get the binary instruction
75         binary_instruction = f"{opcode} {target_reg} {source_reg} {immi}"
76         return binary_instruction
```

```
def execute_instructions(instructions):
          global total_cycle_counts
          print("-----
          print(" PC | User's instruction | Binary Encoed Instruction
                                                                                           Cycles")
          print("-----
 85
          for index, i in enumerate(instructions):
              if i == 'end 0 0':
                  return
              else:
                  binary_instruction = encode_instruction(i)
                  binary_instruction_split = binary_instruction.split()
                  opcode = binary_instruction_split[0]
                  target_reg = binary_instruction_split[1]
                  source_reg = binary_instruction_split[2]
                  immi = binary_instruction_split[3]
                  if immi[0] == '1':
                      immi = int(immi, 2) - (1 << 21)
                  else:
                      immi = int(immi, 2)
                  cycle = cycle_values[opcode]
103
                  total_cycle_counts += cycle
104
                  pc = index
105
                  print(f" {pc:>4} | {i:<20} | {binary_instruction:<36} | {cycle:>6}")
                  if opcode == '00000': #mov
                      if source_reg == '000':
                          gprs_values[target_reg] = immi
110
111
                      else:
```

```
II Source_reg == "" :
TAA
                           gprs_values[target_reg] = immi
110
                       else:
111
112
                           gprs_values[target_reg] = gprs_values[source_reg]
                   if opcode == '00001': #add
114
                      if source_reg == '000':
115
                           gprs_values[target_reg] += immi
116
117
                       else:
                           gprs_values[target_reg] += gprs_values[source_reg]
118
119
                   if opcode == '00010': #sub
120
                      if source_reg == '000':
121
122
                           gprs_values[target_reg] -= immi
123
                       else:
                           gprs_values[target_reg] -= gprs_values[source_reg]
124
125
                   if opcode == '00011': #mul
126
                      if source reg == '000':
127
128
                           gprs_values[target_reg] *= immi
129
                       else:
                           gprs_values[target_reg] *= gprs_values[source_reg]
130
131
                   if opcode == '00100': #div
132
                      if source reg =='000':
133
                           if immi == 0:
134
135
                               print(f"Divided by zero, skip the instruction {pc}")
136
                               continue
                           gprs_values[target_reg] //= immi
137
138
                       else:
                           if gprs values[source reg] == 0:
139
                               print(f"Divided by zero, skip the instruction {pc}")
141
                               continue
                           ones values [target reg] //= ones values [source reg]
```

```
continue
                          gprs_values[target_reg] //= gprs_values[source_reg]
      instructions = [
144
          "mov r1 15",
          "add r1 10",
         "mov r2 5",
         "mul r2 r1",
         "sub r3 r2",
         "div r2 5",
          "mov r4 r3",
          "end 0 0"
      total_cycle_counts = 0
      total_instructions = len(instructions) - 1
     execute_instructions(instructions)
     print("-----
     print("Execution Completed!")
     print()
      print(f"Total Cycle counts after executing all the instructions = {total_cycle_counts}")
     print(f"Total Instruction counts = {total_instructions}")
     print(f"CPI = {round(total_cycle_counts / total_instructions, 2) }")
      print()
     print("After executing instructions, each register contains - ")
     for reg, val in gprs_values.items():
         bit_form = format(val & 0xFFFFFFFF, '032b')
         print(f" {reg:>4} (r{int(reg, 2)}) | {val:<16} | {bit_form}")</pre>
```